

For pure pleasure on the water

The floatable Marine binoculars of the Fujinon WPC series. Ideal for water activities

- ▶ Sailing
- ▶ Fishing
- ▶ Water sports



The WPC series in detail

- ▶ The WPC models have a precision compass with integral illumination: 360° compass rose and 1° scale
- ▶ Large 50 mm objectives for maximum light power bring every detail close to you with precision
- ▶ All models come supplied with permanently attached lens covers for the eyepieces and objective to prevent scratches and keep out dirt, as well as a floating neck strap in bright signal colours
- ▶ The comfortable 18 mm eye relief makes them suitable for eye-glass wearers
- ▶ Thanks to the multi-coated optics you will achieve outstanding image quality over the full glass surface
- ▶ Due to the ultra-light floatable body made of polycarbonate, even if they fall into the water without the floating neck strap, they will always stay afloat



Technical data	7x50WPC-XL 	7x50WP-XL 
Magnification	7x	7x
Objective diameter (mm)	50	50
Eye relief (mm)	18	18
Field of view	7°	7°
Field of view at 1,000 m (m)	122	122
Exit pupil (mm)	7.1	7.1
Twilight factor	18.7	18.7
Adjustment range for interpupillary distance (mm)	56–72	56–72
Dimensions W x H x D (mm)	201 x 180 x 76	201 x 180 x 76
Weight (g)	910	910
Compass accuracy	±5°	–